

56

# Standard Features

- Paint or Stain
- Keyed Entry Door
- Chicken Door
- Chicken Ramp
- Nesting Boxes
- Roosting Bar
- Vent Lid or Vent
- Window with Screen
- Asphalt Shingles
- Aluminum Drip Edge
- 5/8 LP Flooring with 10 year waranty
- P.T. Legs and Runners
- L.P Tech Shield Roof Sheathing

#### Size & Style **Step**(I) Decide on the number of chickens you would like to have. Each coop has a number on the

chicken silhouette that will tell you the recommended amount of chickens for that coop. Note: Chicken Coop sizes do not include outside nesting boxes. Tractor Dutch Quaker Combination Lean-to A-Frame Colors Note: Actual colors may vary from printed samples. Step(2) White Navajo Cream Buckskin Beige paint Light Blue Chestnut Clay Lt. Gray Dark Blue Black Hunter Green Dark Gray Red Avocado

Brown Cedar

stain


Cedar





Natural

Rustic Cedar



## Step (6)

58

# Choose a Cupola & Weathervane



Board & Batten Wood w/ Copper Top



Copper Eagle



Copper Standing Rooster

Copper Horse



Shed Cupola, White



Black Horse





Small Black Rooster

Black Eagle



## Step (7)

# Interior Options



Electric Package Switch / Outlet / Lights Extension Cord Hookup



Heated Roost- Requires electrical package



Epoxy Floor



Wire over window



Insulated Ceiling Standard on metal roof option



30 watt solar panel Solar powered light with switch. Light also available with timer.



# Options



60

Step (8) Exterior Options





## 5'x7'x3' Chicken Run

With Optional Wheel Lift Lever Kit Available with and without wheels.

#### More Sizes Available

## 6'x8'x6' Chicken Run with Roof

Fits all coop styles and sizes Available with or without wheel lift lever (Shown with 4'x6' Quaker)



Vinyl Coated Wire

14 Gauge Vinyl Coated Wire I" x 2" Hole Size Available In Widths Of 2', 3', 4', 5', 6' Lengths Up To 100'



Auge

## Choose An Auto Door

BASIC

## **FEATURES**

- Timer Open/Close
- Manual Open/Close
- GPS Functionality Upgrade Available See website for details.
- Self-explanatory LED Screen
- LED Fault Indicator Light

## POWER SUPPLY

- 110 V Electric (adapter included)
- 4 AA Batteries (batteries not included)
- Solar Kit (not included)

#### DIMENSIONS

33" x 11¾" x 2¾" Hole Opening: 101/2" x 12"



## ADVANCED

## FEATURES

- Sunrise/Sunset Open/Close
- Timer Open/Close
- Manual Open/Close

Note: With GPS functionality, you may visit our website at www.PetAutoDoors.com and find out what your latitude and longitude coordinates are to configure your location. Once entered and saved, you can choose to set for up to 4 hours before/after sunrise and sunset. Your Auto Door will change with the sunrise and sunset automatically!

- Self-explanatory LED Screen
- LED Fault Indicator Light

## POWER SUPPLY

- 110 V Electric (adapter included)
- 4 AA Batteries (batteries not included)
- Solar Kit (not included)

## DIMENSIONS

33" x 11¾" x 2¾" Hole Opening: 101/2" x 12"



## Step 10 Choose a Litter Tray



<b>Litter Tray</b> <b>covering whole floor</b> (requires clean out lid)		
Available for the following:		
D46	D44 ?	
Q34	Q341	
D44	L35T	
A46	A33T	
A44	L34T	
A33	D48	
L45	A57C	
L35	A46C	
L34		



Clean-Out Lid For Litter Tray Shown Below



Clean-Out Lid For Litter Tray Shown Above

Litter Tray covering under roost bars only (requires clean out lid) Available for the following: A124 0716C 072

QIZ	AIZ4	QTIOC
Q712	A80	Q718C
Q58	A60	Q720C
Q56	Q712C	Q722C
Q46 H	Q612C	Q724C
Q46	Q610C	Q726C
D66	Q68C	Q728C
Q44	Q48C	Q732C
Q44T	Q714C	



62

# Step (1) Wheel Options



Four Wheels with Handle Available on Models: Q44, L35, D44, A44, L45



Four Wheels with Steering Handle, Heavy Duty Available on models: Q72,Q712, A80, A60





Wheelbarrow System Available on models: A33, L34, L35


Four Wheels with Steering Handle Available on Models: Q58, Q56, Q46H, Q46, Q48, Q48C, D66, D48, D46, L45



The Wheel Lift Lever is standard on all tractor models. also available on models: A57C, A46C

Wheel Lift Lever Kit Available for all runs.





Shown with pump handle attached which will lift the coop up to 6 in. When not in use, handle can be removed and attached to inside of door.

63